

## FAULT DIAGNOSIS

### Vacuum/hydraulic system

<i>Fault</i>	<i>Possible Cause</i>	<i>Rectification</i>
<b>LOW EFFICIENCY</b>	<ol style="list-style-type: none"> <li>1. Incorrect adjustment.</li> <li>2. Air in system.</li> <li>3. Incorrect, badly fitted, contaminated or distorted linings.</li> <li>4. Linings or drums glazed.</li> <li>5. Load sensing valve incorrectly set or faulty operation.</li> <li>6. Servo unit faulty.</li> </ol>	<p>Check shoe to drum clearances. Bleed system. Renew brake linings.</p> <p>Deglaze as necessary. Check/adjust setting, check operation.</p> <p>Check operation.</p>
<b>PULLING TO ONE SIDE</b>	<p>Before checking brakes check tyre pressures, tyre pairing road springs and dampers.</p> <ol style="list-style-type: none"> <li>1. Contaminated linings.</li> <li>2. Shoes fitted incorrectly i.e. primary and secondary.</li> <li>3. Faulty wheel cylinder or hose (opposite side to pull)</li> <li>4. Loose backplate.</li> </ol>	<p>Renew linings and rectify cause of contamination. Remove and refit shoes correctly.</p> <p>Renew or overhaul as necessary.</p> <p>Tighten to correct torque.</p>
<b>GRABBING</b>	<ol style="list-style-type: none"> <li>1. Contaminated linings or incorrect lining material.</li> <li>2. Primary/secondary shoes interchanged.</li> <li>3. Return spring broken or displaced.</li> <li>4. Backplate loose.</li> <li>5. Excessive hub end float.</li> <li>6. Brake drum tilted or oval.</li> </ol>	<p>Renew linings.</p> <p>Remove and refit correctly. Fit new springs. Tighten new springs. Adjust end float. Remove clean flange or fit new drum.</p>
<b>FADE</b>	<ol style="list-style-type: none"> <li>1. Incorrect adjustment.</li> <li>2. Primary/secondary shoes interchanged.</li> <li>3. Incorrect lining material.</li> <li>4. Drum worn.</li> <li>5. Servo unit faulty.</li> <li>6. Contaminated fluid.</li> </ol>	<p>Check/adjust shoe to drum clearances. Remove and refit correctly. Change linings. Fit new brake drum. Check operation. Change fluid.</p>
<b>BINDING</b> — 1 wheel  All wheels	<ol style="list-style-type: none"> <li>1. Brake over adjusted.</li> <li>2. Shoes seized.</li> <li>3. Broken return spring.</li> <li>4. Swollen wheel cylinder seals.</li> <li>5. Hose obstructed.</li> <li>6. Master cylinder seals</li> <li>7. Servo unit faulty.</li> </ol>	<p>Check/adjust shoe clearances. Lubricate contact areas. Renew springs. Overhaul wheel cylinders. Check hose for kinks. Overhaul master cylinder. Check operation</p>
<b>SQUEAL</b>	<ol style="list-style-type: none"> <li>1. Dust or dirt in drums.</li> <li>2. Contaminated linings.</li> <li>3. Backplate loose.</li> <li>4. Wheel cylinder loose.</li> </ol>	<p>Clean out drums. Change linings.</p> <p>Tighten to correct torque.</p>
<b>EXCESSIVE HANDBRAKE TRAVEL</b>	<ol style="list-style-type: none"> <li>1. Cable stretched.</li> <li>2. Incorrect brake shoe adjustment.</li> </ol>	<p>Re-adjust handbrake. Check/adjust shoe clearances.</p>

**BRAKES****Fault Diagnosis****Air/hydraulic system**

<i>Fault</i>	<i>Possible Cause</i>	<i>Rectification</i>
<b>LOW BRAKE EFFICIENCY</b>	<ol style="list-style-type: none"> <li>1. Brakes not adjusting.</li> <li>2. Air in hydraulic system.</li> <li>3. Load sensing valve faulty, or incorrectly set.</li> <li>4. Brake linings worn.</li> <li>5. Oil or grease on linings or drums.</li> <li>6. Linings or drums glazed.</li> <li>7. Low air pressure.</li> </ol>	<p>Check operation. Check fluid level in master cylinder. Bleed brakes. Check hydraulic system for loss. Test valve. Adjust if necessary.</p> <p>Renew brake linings. Adjust brakes. Renew linings. Renew hub oil seals and/or wheel cylinder rubbers. Deglaze linings and drums. Check that correct linings are being used. Insert test gauges into service reservoirs. If low pressure is confirmed, check compressor, governor valve and quadruple charge protection valve.</p>
<b>BRAKES PULL TO ONE SIDE</b>	<ol style="list-style-type: none"> <li>1. Incorrect tyre pressures.</li> <li>2. Tyres not paired.</li> <li>3. Suspension or steering fault.</li> <li>4. Oil or grease on brake linings.</li> <li>5. Brake shoes wrongly fitted — primary/secondary interchanged, or shoe reversed.</li> <li>6. Backplate loose.</li> <li>7. Wheel cylinder faulty (on opposite side to brake pull).</li> <li>8. Flexible hose blocked (on opposite side to brake pull).</li> </ol>	<p>Inflate tyres to correct pressure. Check for similar tread depth and pattern of tyres on each axle. Check road springs, dampers and steering angles. Renew linings — (both sides) and hub oil seal and/or wheel cylinder rubbers. Fit shoes correctly on backplate, with correct lining. (See Data).</p> <p>Tighten backplate bolts. Renew or overhaul wheel cylinder.</p> <p>Renew flexible hose.</p>
<b>BRAKES GRABBING</b>  May be evident at low speed, when moderate pressure on the pedal results in the brake of one or more wheels suddenly jamming on.	<ol style="list-style-type: none"> <li>1. Brake shoes wrongly fitted — primary/secondary interchanged or shoes reversed.</li> <li>2. Wrong type of lining fitted.</li> <li>3. Brake drum oval.</li> <li>4. Brake shoe return spring(s) broken/displaced.</li> <li>5. Back plate loose.</li> <li>6. Oil or grease on linings or drums.</li> <li>7. Hub bearings loose.</li> <li>8. Brake drum tilted on hub</li> </ol>	<p>Refit shoes correctly, with correct linings.</p> <p>Fit correct lining. See Data. Renew brake drum. Fit new shoe return springs.</p> <p>Tighten backplate bolts. Renew linings. Renew hub oil seal/ or wheel cylinder rubbers. This will allow the drum to tilt in relation to the shoes. Adjust the hub bearings. Clean the hub flange and brake drum face. Refit the drum square, and tighten the nuts evenly.</p>
<b>BRAKES APPLY SLOWLY</b>	<ol style="list-style-type: none"> <li>1. Brakes not adjusting.</li> <li>2. Low air pressure.</li> <li>3. Excessive air leak with brakes applied.</li> <li>4. Restriction in hydraulic line or flexible hose.</li> </ol>	<p>Check operation. Insert test gauges into service reservoirs. If low pressure is confirmed, check compressor, governor valve and quadruple charge protection valve. Check and correct.</p> <p>Examine hydraulic lines for kinks and damage. Check lines and hoses for restriction.</p>

## Fault Diagnosis

<i>Fault</i>	<i>Possible Cause</i>	<i>Rectification</i>
<b>BRAKES RELEASE SLOWLY</b>	<ol style="list-style-type: none"> <li>1. Foot control valve not exhausting freely.</li> <li>2. Restriction in air lines.</li> <li>3. Restriction in hydraulic lines or flexible hoses.</li> <li>4. Wheel cylinder rubbers swollen.</li> <li>5. Brake shoe return springs broken, or incorrectly fitted.</li> <li>6. Master cylinder pistons sticking or seals swollen.</li> <li>7. Tandem actuator pistons sticking.</li> </ol>	<p>Test foot control valve.</p> <p>Examine air lines for kinks and restrictions.</p> <p>Release a hydraulic connection at a wheel cylinder. If the brakes on that axle release quickly, the fault is in the hydraulic lines, master cylinder or actuator.</p> <p>Examine hydraulic lines and flexible hoses for restriction.</p> <p>If brakes do not release quickly when hydraulic connection is released, the fault is within the brake unit.</p> <p>Examine wheel cylinder rubbers, renew if necessary, flush the hydraulic system and renew all rubbers.</p> <p>Examine springs, refit or renew.</p> <p>Release the hydraulic connections at master cylinder. If brakes release quickly the fault is in the master cylinder or actuator. Overhaul as necessary. If seals are swollen, flush the hydraulic system and renew all rubbers.</p> <p>Overhaul actuator.</p>
<b>BRAKES CHATTER</b>	<ol style="list-style-type: none"> <li>1. Brakes not adjusting.</li> <li>2. Hub bearings loose.</li> <li>3. Brake drum oval.</li> <li>4. Brake drum tilted on hub flange.</li> <li>5. Oil or grease on linings.</li> </ol>	<p>Check operation.</p> <p>Adjust hub bearings.</p> <p>Renew brake drum.</p> <p>Clean the hub flange and face of brake drum. Refit the drum and tighten the bolts evenly.</p> <p>Renew linings. Renew hub oil seal and/or wheel cylinder rubbers.</p>
<b>BRAKES SQUEAL</b>	<ol style="list-style-type: none"> <li>1. Dust or dirt in brake drum.</li> <li>2. Oil or grease on drum or lining.</li> <li>3. Foreign material embedded in brake lining.</li> <li>4. Brake back plate loose.</li> <li>5. Wheel cylinder or brake adjuster loose.</li> <li>6. Brake lining loose on brake shoe.</li> <li>7. Bent or distorted brake shoes or back plate.</li> </ol>	<p>Clean out the brake assemblies.</p> <p>Renew linings. Renew hub oil seal and/or wheel cylinder rubbers.</p> <p>Renew linings.</p> <p>Tighten back plate securing bolts.</p> <p>Tighten the securing bolts.</p> <p>Renew lining and shoe assembly.</p> <p>Renew damaged parts.</p>
<b>BRAKES FADE</b>	<ol style="list-style-type: none"> <li>1. Brakes not adjusting.</li> <li>2. Incorrect brake lining fitted, or primary/secondary shoes interchanged.</li> <li>3. Excessive air leak at actuator, or between foot control valve and actuator.</li> <li>4. Brake drums ground excessively.</li> </ol>	<p>Check operation.</p> <p>Check that brake shoes are fitted correctly, and with the correct linings. (See Data).</p> <p>Test for air leaks with brakes applied.</p> <p>Renew brake drums.</p>

**BRAKES****Fault Diagnosis**

<i>Fault</i>	<i>Possible Cause</i>	<i>Rectification</i>
<b>BRAKE BINDING – ONE WHEEL</b>	<ol style="list-style-type: none"><li>1. Brake over-adjusted.</li><li>2. Brake shoes tight/seized on backplate.</li><li>3. Brake shoe return spring broken.</li><li>4. Brake shoe distorted.</li><li>5. Wheel cylinder rubbers swollen.</li><li>6. Flexible hose blocked (front only).</li><li>7. Obstruction in hydraulic line.</li></ol>	<p>Adjust brake. Lubricate and refit brake shoes.</p> <p>Renew spring. Renew brake shoe. Renew rubbers, flush hydraulic system and renew all rubbers. Release hydraulic connection at wheel cylinder. If brake releases, fault is in hose or hydraulic line. Renew hose. Examine hydraulic line for kinks and restrictions.</p>
<b>BRAKES BINDING – ALL WHEELS</b>	<ol style="list-style-type: none"><li>1. Foot control valve not fully exhausting.</li><li>2. Master cylinder pistons sticking or seals swollen.</li><li>3. Incorrect clearance between master cylinder and actuator.</li><li>4. Tandem actuator pistons sticking.</li></ol>	<p>Test foot control valve.</p> <p>Overhaul master cylinder. If seals are swollen, flush the hydraulic system and renew all rubbers. Check and if necessary adjust the clearance. Overhaul the actuator.</p>
<b>PARK BRAKE NOT APPLYING</b>	<ol style="list-style-type: none"><li>1. Quick release valve not exhausting.</li><li>2. Hand control valve not exhausting.</li><li>3. Compensator linkage incorrectly adjusted.</li><li>4. Wind-off mechanism of spring brake actuator not fully released.</li><li>5. Auto-release valve faulty.</li></ol>	<p>Test the quick release valve. Test the hand control valve. Check and adjust the compensator linkage. Check wind-off mechanism.</p> <p>Check operation.</p>
<b>PARK BRAKE NOT RELEASING</b>	<ol style="list-style-type: none"><li>1. Hand control valve faulty.</li><li>2. Excessive air leak in air line, hand control valve to spring brake actuator.</li><li>3. Excessive air leak in park brake circuit.</li><li>4. Piston sticking or seized in spring brake actuator.</li></ol>	<p>Test the hand control valve. Test for air leaks with hand control valve in 'OFF' position. Test for air leak.</p> <p>Overhaul spring brake actuator.</p>