

SECTION G

AUTOMATIC TRANSMISSION

Index to Sub-sections

DATA	G101
Tightening torques	page 1
Data	page 2
SPECIAL TOOLS	G102
DESCRIPTION AND MODIFICATIONS	G103
FAULT DIAGNOSIS	G104
IN-SITU OPERATIONS	G110
Drain, renew filter and refill	page 1
Pressure tests	page 1
Band adjustments	page 6
Speedometer pinion gear	page 7
Neutral starting and reverse light switch	page 7
Gearshift linkage adjustment	page 8
Throttle rod adjustment	page 8
Rear extension seal	page 9
Valve block	page 9
Manual lever shaft seal	page 10
Adjusting the hydraulic pressures	page 16
TO REMOVE AND REFIT	G120
Automatic transmission	page 1
OPERATIONS WITH BOX REMOVED	G130
Pump oil seal renewal	page 1