

Assembly, Maintenance and Operating Instructions

Contents

	Page
I. Technical Data	2
II. Description	2
III. Handling	6
IV. Maintenance and Lubrication	6
V. Tools	8
VI. Disassembly of Transmission	10
VII. Checking of Individual Components	14
VIII. Assembly of Transmission	14
IX. Ordering Spare Parts	24
X. Key to Illustrations	24
XI. Exploded Views	26