

SECTION M

BRAKES

SECTION

INDEX	MA000
DESCRIPTION (INC. DIAGRAMATIC LAYOUT)	MA010
DATA	MA020
TIGHTENING TORQUES	MA030
SPECIAL TOOLS	MA040
FAULT DIAGNOSIS (VAC./HYD.)	MA050
FAULT DIAGNOSIS (AIR/HYD.)	MA055

FRONT BRAKES

4 x 46M Disc Brake Caliper	MA110
2 x 50 Pin Slider Caliper	MA120
13 x 4 TWO LEADING SHOE	MA130
13 x 5 TWO LEADING SHOE	MA140

REAR BRAKES

12½ x 4 DUO SERVO	MA150
13 x 5½ DUO SERVO	MA160

BLEEDING THE HYDRAULIC SYSTEM	MA190
-------------------------------------	-------

MASTER CYLINDER (VAC./HYD.)	MA200
MASTER CYLINDER (AIR/HYD.) HAULAGE	MA210
MASTER CYLINDER (AIR/HYD.) P.S.V.	MA220

SERVO UNIT (VAC./HYD.)	MA250
TANDEM ACTUATOR (AIR/HYD.) HAULAGE	MA260
TANDEM ACTUATOR (AIR/HYD.) P.S.V.	MA270

Index**SECTION**

HANDBRAKE AND LINKAGE..... MA300

SPRING BRAKE AND COMPENSATOR..... MA320

VALVES

Dual Brake Valve..... MA400

Hand Control Valve..... MA405

Governor Valve..... MA410

Quadruple Protection Valve..... MA415

Quick Release Valve..... MA420

Load Sensing Valve..... MA425

ANTI-FREEZE UNIT..... MA450

AIR LINE FILTER..... MA455

LOW PRESSURE WARNING SWITCHES..... MA460

AIR RESERVOIRS AND FITTINGS..... MA500

COMPRESSOR..... MA600



**WARNING
CONTAINS
ASBESTOS**

Breathing asbestos
dust is dangerous
to health.

Follow safety
instructions.

ASBESTOS ALERT

The vehicle described in this publication incorporates components containing asbestos.

Working with them can create dust. Breathing this dust is harmful. Cases of asbestos related cancer have been reported in garage workers.

The dangerous jobs are: ● cleaning brake assemblies ● cleaning clutch housings
● grinding brake linings ● drilling brake linings ● sweeping floors

Brake and clutch linings and disc pads may contain asbestos. If in doubt assume that they do.

WHO IS AT RISK?

Anyone in the garage could be at risk. There is no known safe level of asbestos dust. But the more dust you breathe the greater the chance of lung damage.

The problem is that the dust particles are too small to be seen by the naked eye. And the diseases caused can take years to develop.

Don't put the brakes on your life. Avoid breathing asbestos dust. Prevent dust getting into the air. Follow the GARAGE WORKERS' ASBESTOS CODE.

GARAGE WORKERS' ASBESTOS CODE

1. DON'T blow dust out of brake drums or clutch housings with an air line.
2. DO use properly designed drum cleaning equipment which prevents dust escaping, or use clean wet rags to clean out drums or housings. Put used rags in a plastic waste bag while still wet.
3. DON'T grind or drill linings unless the machine has exhaust ventilation or there is a ventilated booth to do the work in.
4. DON'T use brushes to sweep up dust.
5. DO use a special (Type H) vacuum cleaner to remove dust.
6. DO wet dust *thoroughly* and scrape it up if you haven't got a vacuum.
7. DO wear the protective clothing, such as overalls, provided by your employer.
8. DON'T take the protective clothing home. It should be cleaned by your employer.
9. DON'T use equipment if it is not maintained and checked. Ask to see the examination reports for ventilation systems.